




FABARM

NOTE: All part numbers ordered from Heckler & Koch, Inc. have a "00" suffix.
For instance, part number R80 in the chart below would be part number R8000 in the HK Parts List.



Fabarm #	HK Part #	Description
P03	P0300	Main spring
P06	P0600	Stock bolt
P09	P0900	Multiuse ring spring pin
P16	P1600	Sear retaining pin
P17	P1700	Sear spring single trigger
P20	P2000	Safety retaining pin(single trigger)
P21	P2100	Single select trigger safety
P33	P3300	Ejector spring plunger
P42	P4200	Barrel swivel
P43	P4300	Stock swivel
P46	P4600	Ejector plate pin
P53	P5300	Fluorescent sight
P73	P7300	Trigger regulation screw
P74	P7400	Trigger regulation screw
P96	P9600	Single selective trigger
P97	P9700	Inertia block spring
P98	P9800	Inertia block retaining pin
P99	P9900	Trigger retaining pin
P100	P10000	Trigger return spring
P101	P10100	Stock bolt washer
P102	P10200	Elastic washer
R01	R0100	Cover plate of action body
R02	R0200	Barrel pivot pin
R03	R0300	Barrel pivot pin screw
R04	R0400	Top lever
R05	R0500	Strikers retaining rod
R06	R0600	Cover plate retaining pin
R07	R0700	First lever spring
R08	R0800	Lever spring plunger
R09	R0900	Locking bolt
R10	R1000	Bolt retainer
R11	R1100	Bolt retaining spring
R12	R1200	Cocking rod

Fabarm #	HK Part #	Description
R13	R1300	Cocking rod spring
R14	R1400	Bolt plate screw
R15	R1500	Second lever spring
R16	R1600	Left striker
R17	R1700	Cocking cam
R18	R1800	Striker spring
R19	R1900	Bolt retaining plate
R20	R2000	Ejector cocking rod right
R21	R2100	Ejector cocking rod left
R22	R2200	Right ejector cam
R23	R2300	Left ejector cam
R24	R2400	Right trigger
R25	R2500	Cocking rod plunger
R27	R2700	Forend iron
R28	R2800	Forend catch
R29	R2900	Forend catch screw
R30	R3000	Ejector lever
R31	R3100	Ejector lever spacer
R32	R3200	Ejector levers pin
R33	R3300	Cocking cam trip
R34	R3400	Cocking cam trip pin
R35	R3500	Standard forend wood
R36	R3600	Forend retaining screw
R37	R3700	Forend front unit
R38	R3800	Standard forend catch button
R39	R3900	Forend catch button retaining
R40	R4000	Forend catch button spring
R41	R4100	Ejector lever spring
R42	R4200	Forend back unit
R44	R4400	Right ejector
R45	R4500	Left ejector
R46	R4600	Ejector spring
R47	R4700	Ejector retaining pin

Fabarm #	HK Part #	Description
R48	R4800	Ejector retaining pin spring
R49	R4900	Right hammer
R50	R5000	Left hammer
R51	R5100	Trigger guard
R52	R5200	Trigger guard back pin
R53	R5300	Trigger ret pin & guard front pin
R55	R5500	Single sel. trigger safety spring
R58	R5800	Automatic safety rod
R67	R6700	Semi-beavertail forend
R68	R6800	Beavertail forend catch button
R70	R7000	Right sideplate (not engraved)
R71	R7100	Left sideplate (not engraved)
R72	R7200	Front screw for side plate
R73	R7300	Rear screw for side plate
R78	R7800	Right sear
R79	R7900	Left sear
R80	R8000	Right pistol grip stock
R81	R8100	Left pistol grip stock
R84	R8400	Barrel swivel support
R99	R9900	Main spring guide
R100	R10000	Main spring nut
R101	R10100	Main spring nut stop
R102	R10200	Left sear double hooking
R103	R10300	Right sear double hooking
R104	R10400	Left hammer double hooking
R105	R10500	Right hammer double hooking
T33	T3300	Inertia block
T34	T3400	Single trigger inertia block
V07	V0700	Tumbler retaining pin
V25	V2500	Brass sight
V99	V9900	Inertia block ball