



- 1 Front sight
- 2 Slide
- 3 Rear sight
- 4 Safety catch
- 5 Recoil spring
- 6 Barrel
- 7 Extractor
- 8 Locking rollers
- 9 Compression spring
- 10 Pressure pin
- 11 Spring for pressure pin
- 12 Drag lever
- 13 Clamping sleeve
- 14 Compression spring
- 19 Firing pin spring
- 20 Firing pin
- 21 Spiral pin
- 22 Bolt head
- 23 Set screw
- 24 Compression spring
- 25 Catch bolt
- 26 Cylindrical pin
- 27 Bolt head carrier
- 28 Buffer support
- 30 Lens head countersunk screw
- 31 Buffer housing
- 32 Plastic buffer
- 34 Barrel catch
- 35 Insert piece
- 36 Trigger stop
- 37 Trigger
- 38 Compression spring
- 40 El bow spring
- 41 Clamping sleeve
- 42 Catch lever
- 43 Catch spring
- 44 Disconnecter
- 45 Cylindrical pin
- 46 Pull bar
- 47 Trigger bar
- 48 Spring for pull bar
- 49 Indicator pin
- 50 Spiral pin
- 51 Hammer
- 52 Stop pin
- 53 Spring for disconnecter
- 54 Axle for hammer
- 55 Threaded bush
- 57 Trigger guard
- 58 Receiver
- 59 Safety latch
- 60 El bow spring
- 61 Cocking lever
- 62 Catch
- 63 Countersunk screw
- 64 Bearing plate, left
- 65 Angle lever
- 66 Intermediate lever
- 67 Bearing plate, right
- 68 Shank
- 69 Compression spring for hammer
- 70 Magazine catch
- 71 Grip
- 72 Lenshead countersunk screw
- 73 Magazine housing
- 74 Follower
- 75 Follower spring
- 76 Support for follower spring
- 77 Magazine floor plate