

## Instructions

- 1. Make sure firearm is unloaded
- 2. Remove factory magwell and trigger group
- 3. Disassemble the trigger group by removing the hammer and factory bolt stop with pin and spring
- 4. Mount the Spuhr Bolt Stop Assembly (no. 8) with the factory spring and Hardened Pin (no.5) in the trigger group, then reinstall the hammer and assemble the firearm
- 5. Install Spuhr G36 Magwell Assembly into firearm

Clean and lubricate in accordance with H&K manual.

Note: To reconvert firearm reinstall factory bolt stop and magazine well.

							PΔ	RTS
	ITEM		QTY	PART NUMBER				
	1		1	R-0008				
	2		1	R9				
	3		1	R10				
	4		1	R11				
	5		1	R18				
	6		3	R19				
	7 8 9		5	R20				
			1	R16				
			1	R12-2				
	Desig		ned by		Checke	d by	Approved by	
		Håka	an					
		Spuhr AB						
								<u> </u>
								R-
		3			I			2

Spuhr G36 Magwell Assembly for M16 style magazines. Due to variances betwen various M16 style magazines, this magazine well is optimized to work with Magpul PMAG and HK416 magazines, but will work well with most M16 style magazines. Compartment in rear of magbox is for CR-2032 battery.

Metal parts are made from 7075 T651 with pins and springs in stainless steel. All major parts are engraved with part and batch numbers.

5

6

A



D

С

